
TOUGHDOG NVRs RECOMMENDED CONNECTION DIAGRAM









TOUGHDOG NVRs RECOMMENDED CONNECTION DIAGRAM






TOUGHDOG NVRs WIRING NOT RECOMMENDED CONNECTION DIAGRAM






TOUGHDOG NVRs WIRING NOT RECOMMENDED CONNECTION DIAGRAM







Point-Point or Point-Multipoint configuration cannot be connected to the back of an NVR for the following reasons:

- 1.-Every internal port was designed to power up and bandwidth for a single camera.
- 2.-recorder cannot recognize cameras over this configuration, (plug and play function lost).
- 3.-A power issue either on the recorder or antenna will happen eventually.